- For all types of wood
- Floors, garden furniture, shutters, doors, fences
- Especially for outdoor use

# **PREPARATION**

- Application to raw wood without a trace of finish (oil, varnish, impregnation varnish...): if necessary, scrub with sandpaper 40, 60 and 100, to restore the wood or use the corrosive Décapant Syntilor.
- In order to optimize the action of the product, it is recommended to wet the wood before application, to open the pores.

# APPLICATION

- Ready-to-use product, do not dilute.
- Shake well before use.
- Gloves, goggles and protective clothing are recommended.
- Apply the Dégriseur Nettoyant with a brush, brush or roller (long bristles), in the direction of the wood fibers. In the case of vertical surfaces, work from top to bottom.
- Leave on for 10 to 15 minutes maximum. Scrub, if necessary, with a nylon brush (bristles) to perfect the action of the product (caution: risk of splashing).
- Rinse with plenty of water.
- If necessary, make a second application, under the same conditions.
- Allow to dry for 48 to 72 hours before applying the selected finish.
- Please note that the final color of the wood will only appear after the finish has been applied.

DENSITY (at 20°C)	1,01 (± 0,03)
ASPECT	Gel
ACTION TIME (at 20°C)	10 to 15 minutes
DRY TIME AFTER APPLICATION (at 20°C)	
	48 to 72 hours
YIELD	5 - 8 m² per Liter per layer

# FEXNING & PRESERVATION TECHNICAL SPRECAUTIONS

- To be used in conditions of good ventilation.
- Do not apply at temperatures below 12°C or above 25°C.
- DANGEROUS. OBSERVE THE PRECAUTIONS FOR USE.
- Keep out of reach of children.
- Store in its original packaging for 2 years, carefully closed after use.
- Store away from frost, heat and moisture.
- The Safety Data Sheet for this product is available on our website www.interkas.gr or www.syntilor.com

# **TOOLS**



## **TOOL CLEANING**

